

GA CASE STARTUP CHECKLIST

When to use:



At the beginning of every general anesthesia case

Pre-Induction Checklist:



High-pressure circuit test



Oxygen fresh gas flow and APL valve open



Suction on and accessible



Airway equipment ready



IV Patent and Meds for induction ready



Baseline Vitals – EKG, SpO₂, BP



BP cycle time q 1 minute



Epic data collection on



PPE

Post-induction Checklist:



Check settings and initiate mechanical ventilation



Turn DOWN fresh gas flow and set vaporizer



Set BP cycle time to less frequent than q 1 minute



Adjust IV fluid flow rate



Verify Pre-incision Antibiotics (drug & dosage)



Temperature management